Norfolk DC Smart Series Installation Guide

Thanks for choosing our Norfolk DC Smart Series ceiling fan. We strongly recommend that you read this manual carefully before installation.

Models Parameters (Fan Only):

MNDC123 WN	1220mm 3 Blade DC WiFi Ceiling Fan Matt White/Natural
MNDC123 WW	1220mm 3 Blade DC WiFi Ceiling Fan Matt White/Whitewash
MNDC123MW	1220mm 3 Blade DC WiFi Ceiling Fan Matt Black/Walnut
MNDC143 WN	1420mm 3 Blade DC WiFi Ceiling Fan Matt White/Natural
MNDC143 WW	1420mm 3 Blade DC WiFi Ceiling Fan Matt White/Whitewash
MNDC143MW	1420mm 3 Blade DC WiFi Ceiling Fan Matt Black/Walnut


Models Parameters (Fan and LED Light):

MNDC1233 WN	1220mm 3 Blade DC WiFi Ceiling Fan Matt White/Natural
MNDC1233 WW	1220mm 3 Blade DC WiFi Ceiling Fan Matt White/Whitewash
MNDC1233MVV	1220mm 3 Blade DC WiFi Ceiling Fan Matt Black/Walnut
MNDC1433 WN	1420mm 3 Blade DC WiFi Ceiling Fan Matt White/Natural
MNDC1433 WW	1420mm 3 Blade DC WiFi Ceiling Fan Matt White/Whitewash
MNDC1433MW	1420mm 3 Blade DC WiFi Ceiling Fan Matt Black/Walnut


Part List:

Qty 1x Motor assemblyQty 1x Instruction manualQty 1x Mounting bracketQty 1x Remote & ReceiverQty 3x Blade fixing metal plate

Qty 1x Screw kit Qty 3x Blades Qty 1x LED light kit (with light models only) Qty 1x Bottom plate (no light models only)



Application



Cooling

E: sales@martecltd.com.au | P: 02 8778 7500 www.martecaustralia.com.au



IMPORTANT SAFEGUARDS:

Means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

The replacement of parts of the safety suspension system device shall be performed by the manufacturer, its service agent or suitably qualified persons.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.


Children should be supervised to ensure that they do not play with the appliance.

- the fixing means for attachment to the ceiling such as hooks or other devices shall be fixed with a sufficient strength to withstand 4 times the weight of the ceiling fan;

- that the mounting of the suspension system shall be performed by the manufacturer, its service agent or suitably qualified persons;

- that the fan is to be installed so that the blades are more than 2,1m above the floor.


WARNING: If unusual oscillating movement is observed, immediately stop using the ceiling fan and contact the manufacturer, its service agent or suitably qualified persons.




How to Assemble



How to Install




How to Install Blades






How to Install Light Plate




How to Install






How to Install




How to Install






How to Install



WOBBLE:


- Ceiling fans are designed to move during operation because they are not generally rigidly mounted
- Movement of a couple of centimetres is acceptable for safe operation.
- Balancing kits included should be used to adjust the balancing when first installed.

Complete





Wire Connections



6* Year Warranty

CE KOHS \otimes Visit our website for details https://www.martecaustralia.com.au/wp-content/uploads/2023/05/Warranty-Statement_Cooling.pdf

WARNING

- Installation of fans MUST follow SAA standards and meet local authority regulations.
- Installation MUST be carried out by a qualified and licensed electrician. .
- . Fan and light MUST be earthed.
- Bracket MUST be firmly attached to a flat solid structure or timber frame. •
- DO NOT mix blades from one model to another, all blades MUST be replaced if damaged. .
- The warranty is VOID if product is not installed according to this installation guide.



Smart Life matching process, please follow the steps:

1.Download the "Smart Life" APP on your smart devices by scanning the QR code below with camera.



2.Turn on WiFi and Bluetooth on your smart devices. Ensure it's connected to a 2.4GHZ WiFi.

3.Open the APP, follow the steps to register new user account or login existing account.



4.Follow instructions in main manual (steps can also be found on the back of the remote) to put the fan into WiFi pairing mode. If the operation is successful, go to step 6. If the fan has previously been paired or you can't get it to work, please go to step 5 to RESET the fan.

5.RESET the fan. This step is NOT necessary if the fan has successfully entered WiFi pairing mode in the last step, if not, try to RESET the fan: turn on the fan, power off after 10 seconds, power on again after 15 seconds, long press "Fan Stop" for 5 seconds, if "beep beep" are heard, the reset is successful. If "beep beep" is not heard, the reset is failed, please repeat this step.

6.Once the fan has entered WiFi pairing mode, open the APP again on the smart device. Click "Add Device" in the middle or the "+" on the top right of the screen.




7. The auto scan should begin automatically, and the fan should show up at the top of screen within a few seconds.

Note: If the fan is not showing up, you can add it manually by clicking and navigate to: >Add Manually >Small Home Appliance > Fan

1:67 0 AddDevice 33 Searching for nearby levices. Make sam hos entered pairing methy derice Add Manually 11 1.1 11 Socket (7igtor) Plug (BLE+WEFT Socket (MI-FE) 1.1 11 1.1 Social Dualband Rug Social (SLE) (240-6550-6) (NS -61) Small Horse 11 Kitchen Annianne Sockal, Johnd Exercise & Heath Prover Strip Carreno & Lock < VV = VV Central Central Power State Power State (REEHWER) (WER) Power Strip (Zigbee) Duritor







E: sales@martecltd.com.au | P: 02 8778 7500 www.martecaustralia.com.au

WiFi / Remote Control Pairing

Fan only model		Fan LED Light Model	
 Pairing the remote control 1. Turn on the ceiling fan. 2. Within the first 20 seconds, continue pressing the button until you hear a "beep" sound. ie. It is paired. If you don't hear a "beep" sound, repeat step 1 and step 2 again. 		 Pairing the remote control 1. Turn on the ceiling fan. 2. Within the first 20 seconds, continue pressing the button until you hear a "beep" sound. ie. It is paired. If you don't hear a "beep" sound, repeat step 1 and step 2 again 	
Entering WiFi Pairing mode: 1.Turn on the power. 2.Within the first 20 seconds, press and hold the "	1h 4h 8h	Entering WiFi Pairing mode: 1.Turn on the power. 2.Within the first 20 seconds, press and hold the " - ♀ · " button until a 'beep" is heard. 3.Continue step connect on your smart devices	Ih 4h 8h
If you don't hear a "beep" sound, repeat the above	steps.	to complete the pairing. If you don't hear a "beep" sound, repeat the above	e steps.
	wer speed to speed. lerly and breeze. er reverse mode. stop 4H, fan will		lower speed to t speed. elderly and e breeze. nter reverse mode. to stop

Visit our website for details
Wisit our website for details
https://www.martecaustralia.com.au/wp-content/uploads/2023/05/Warranty-Statement_Cooling.pdf

WARNING

- Installation of fans MUST follow SAA standards and meet local authority regulations.
- Installation MUST be carried out by a qualified and licensed electrician.
- Fan and light MUST be earthed.
- Bracket MUST be firmly attached to a flat solid structure or timber frame.
- DO NOT mix blades from one model to another, all blades MUST be replaced if damaged.
- The warranty is VOID if product is not installed according to this installation guide.

